



**OMNIEYE  
SECURITY**

a brand of Spark

Omnieye Fixed Lens Camera  
User Manual



## Confidentiality Notice

Copyright © Spark. All rights reserved.

This document is authored by Spark and is Spark intellectual property, including the copyrights in all countries in the world. This document is provided under a license to use only with all other rights, including ownership rights, being retained by Spark. This file may not be distributed, copied, or reproduced in any manner, electronic or otherwise, without the express written consent of Spark.



## Table of contents

<b>1.</b>	<b>CONNECTION</b>	<b>5</b>
1.1	CONNECTING FROM COMPUTER	5
<b>2.</b>	<b>HOME PAGE</b>	<b>6</b>
<b>3.</b>	<b>LIVE VIEW</b>	<b>7</b>
<b>4.</b>	<b>PLAYBACK</b>	<b>9</b>
<b>5.</b>	<b>CONFIGURATION</b>	<b>10</b>
5.1	ENCODE	10
5.2	IMAGE	10
5.2.1	<i>Exposure</i>	10
5.2.2	<i>White Balance</i>	12
5.2.3	<i>Basic Setting</i>	12
5.3	VIDEO	13
5.3.1	<i>Privacy Zone</i>	13
5.3.2	<i>Enhanced Codec</i>	13
5.4	NETWORK	14
5.4.1	<i>General</i>	14
5.4.2	<i>FTP Server</i>	15
5.4.3	<i>SFTP Server</i>	15
5.4.4	<i>RTSP</i>	15
5.4.5	<i>SNMP</i>	16
5.4.6	<i>802.1X</i>	17
5.4.7	<i>Firewall</i>	17
5.4.8	<i>DDNS</i>	17
5.4.9	<i>SSL</i>	18
5.4.10	<i>QoS</i>	18
5.5	SYSTEM	18
5.5.1	<i>Date &amp; Time</i>	18
5.5.2	<i>Firmware</i>	19
5.5.3	<i>Initialization</i>	19
5.5.4	<i>OSD</i>	20
5.5.5	<i>Events</i>	20
5.5.6	<i>Web Log</i>	21
5.6	ACCOUNT	21
5.6.1	<i>Account Management</i>	21
5.6.2	<i>LDAP</i>	22
5.7	EVENT SOURCE	22
5.7.1	<i>Handlers</i>	23
5.7.2	<i>Arming Schedule Setting</i>	23
5.7.3	<i>Defocus</i>	23
5.7.4	<i>Motion</i>	23
5.7.5	<i>Network</i>	24
5.7.6	<i>Schedule</i>	24
5.7.7	<i>Tamper</i>	25
5.7.8	<i>MSD Healthiness</i>	25
5.8	EVENT SETTING	25
5.8.1	<i>Email</i>	25



5.8.2	<i>FTP</i> .....	26
5.8.3	<i>Record Setting</i> .....	26
5.8.4	<i>SD card</i> .....	27
5.8.5	<i>Snapshot</i> .....	28
5.8.6	<i>HTTP Generic Event</i> .....	28



## 1. CONNECTION

### 1.1 Connecting from computer

First make sure the camera and computer are on the same subnet. Then, start a browser and enter the default IP address 192.168.1.219. A login window as shown below will pop up.

Insert username and password to access camera. Default username is admin. There is no default password for security reasons. Insert a new password for admin. The password must be at least 8 characters and must contain at least 1 uppercase letter, 1 special character and 1 alphanumeric character.

The login interface for Omnieye Security. It features the Omnieye Security logo on the left, which consists of a blue eye-like shape. To the right of the logo, the text "OMNIEYE SECURITY" is displayed in a large, bold, black font. Below the logo and text, there is a login form with the following fields: "User Name" with a text input field, "Password" with a text input field, and "Language" with a dropdown menu currently set to "English". A black "Login" button is positioned below the language dropdown.

**OMNIEYE  
SECURITY**

User Name

Password

Language  
English ▼

Login



## 2. HOME PAGE

1


2

3

4

5


6







1	Live view	Click to access camera live view. Live view is also the default landing page when logging in to the camera web interface.
2	Playback	Click to access camera playback.
3	Configuration	Click to access camera configuration.
4	Language	Click the dropdown menu to select interface language.
5	User level	Displays the current user level accessing the camera.
6	Logout	Click to logout.



### 3. LIVE VIEW



1	Media player	<ul style="list-style-type: none"> <li>- ActiveX: provides full functionality, better image quality and lower bandwidth consumption in Live View page. Only available for Internet Explorer.</li> <li>- JPEG / H.264: provides lower frame rate display but offers broader browser compatibility, including Chrome, Opera, etc.</li> </ul>
2	Streams	Up to 3 streams available. Note: this feature is only available in ActiveX mode.
3	Icons	<ul style="list-style-type: none"> <li> Snapshot: click to take a snapshot.</li> <li> Full screen: click for full screen display. Press ESC to go back.</li> <li> Manual recording: click to start manual recording. A red dot icon will appear on the upper-right corner to indicate live image is being recorded.</li> <li> Zoom control: click the icon, then move the mouse over the live view image and scroll to perform digital zoom in/out.</li> </ul> <p>Note: JPEG mode only supports snapshot. Use ActiveX mode to enjoy full feature.</p>
4	Scalable frame rate	<p>Allows user to dynamically adjust frame rate on browser for smooth video display.</p> <ul style="list-style-type: none"> <li>- Full: displays full frame rate according to settings under Encode page.</li> <li>- 1/2: displayed frame rate will be reduced to one half.</li> <li>- 1/4: displayed frame rate will be reduced to one quarter.</li> </ul> <p>Note: Use ActiveX mode and turn on SVC-T before using this function.</p>



5	Live view jitter buffer length	<p>Live View Jitter Buffer Length decides when to transmit media packets for Live View display based on packets it has collected, packets it is still waiting for, and the timing required to playback the media.</p> <p>Dragging the adjustable bar of “Live View Jitter Buffer Length” to higher value lessen the negative effect, namely choppy live video display, caused by transmission delay arising from network congestion. However higher values also increase overall transmission latency.</p> <p>Note: this feature is only available in ActiveX mode.</p>
---	--------------------------------	---





## 4. PLAYBACK

After logging in to the camera, click on Playback to access videos stored on the MicroSD card. Make sure the browser supports the video format. It is recommended to use Chrome or Safari.

The screenshot shows the Omnieye Security Playback interface. On the left, there are several configuration sections: 'Storage device' (SD Card), 'Event Type' (Network Loss, Tamper, Defocus, Schedule, Motion), and 'Date & Time' (September 2021 calendar). Below these is a search bar and an 'Interval' slider set to 1 hour. The main display area shows a timeline for 2021/09/23 from 16:30 to 17:10. A yellow vertical line marks the time 16:49:45. A legend at the bottom identifies event types: SD File (blue), Motion (orange), Tamper (cyan), Defocus (brown), Schedule (green), and Network Loss (light blue). A message in the center of the display area reads: 'There is not any video list. Please setup the filter condition and press search button.'

1	Storage device	Supports MicroSD card from the camera.
2	Event type	Select the type of event that triggered the video recording you are searching for. Available options include motion, tamper, defocus, schedule, network loss.
3	Date & Time	Select the date and time of the video recording you are searching for. Click the search button to start searching videos according to the above configurations.
4	Interval	Define the interval of timeline area in terms of hours.
5	Timeline	Available recordings on the selected time and event will be shown on the timeline.
6	Display	Click on the colored bar on the timeline area and recorded video will automatically start playing on the display.



## 5. CONFIGURATION

### 5.1 Encode

1

Profile

Current Profile: 3

Corridor: Off

Stream1

Compression: 1920x1080

DSCP: 0 (0-63)

Frame Rate: 7

Rate Control: CVBR

Max Bit Rate: 1000 (64-8000)

Codec: H265

Profile: Main Profile

SVC-T: Off

GOP: 60 (1-60)

Stream2

Compression: 1280x720

DSCP: 0 (0-63)

Frame Rate: 15

Rate Control: CVBR

Max Bit Rate: 1000 (64-8000)

Codec: H265

Profile: Main Profile

SVC-T: Off

GOP: 30 (1-60)

Stream3

Compression: 640x360

DSCP: 0 (0-63)

Frame Rate: 30

Rate Control: CVBR

Max Bit Rate: 2000 (64-20000)

Codec: H264

Profile: Main Profile

SVC-T: Off

GOP: 30 (1-60)

2

1	Profile	Select the profile to configure.
2	Stream	<p>Configure each stream depending on the network environment and application.</p> <p><b>Compression:</b> select a resolution. Available options depend on camera model.</p> <p><b>DSCP:</b> define DSCP value for bandwidth management. Bigger value means higher priority.</p> <p><b>Frame rate:</b> define the frequency at which images are captured per second.</p> <p><b>Rate control:</b> available options include CBR, CVBR, VBR. For CBR or CVBR, please use the default bit rate for better balance between image quality and network bandwidth. For VBR, choose quality level based on your needs. VBR is only available in ActiveX mode.</p> <p><b>Codec:</b> select codec. Available options include MJPEG, H.264, H.265.</p> <p><b>Profile:</b> available options depend on selected codec. H.264 supports Main profile and High profile. H.265 only supports Main profile.</p> <p><b>SVC-T:</b> enable this feature to effectively adjust video quality depending on client device.</p> <p><b>GOP:</b> select the value length of group of pictures. Smaller value provides better image quality but more network bandwidth.</p>

### 5.2 Image

#### 5.2.1 Exposure

This section mainly allows user to control the settings pertaining to exposure mode and day night modes.

1

Basic Setting

Exposure Mode: Auto

Digital WDR: Off


Max Shutter time: 1/30


Min Shutter time: 1/10000

EV: 0

BLC: Off



1	Basic setting	<p><b>Exposure mode:</b> select the exposure mode according to your needs.</p> <ul style="list-style-type: none"> <li>- Auto: automatically determines the correct exposure.</li> <li>- Flickerless: overrides the shutter speed to avoid interference of fluorescent lights.</li> <li>- Shutter priority: allows user to select specific shutter speed.</li> <li>- Manual: manually control gain value and shutter speed.</li> <li>- True WDR: provides clear images even when extreme bright and dark areas exist simultaneously. Note: when enabled, max frame rate will decrease to 30fps.</li> </ul> <p><b>Digital WDR:</b> optimizes image quality by adjusting the gamma value, providing clear images even when extreme bright and dark areas exist simultaneously.</p> <p><b>Max shutter time:</b> only available when auto exposure mode is selected.</p> <p><b>Min shutter time:</b> only available when auto exposure mode is selected.</p> <p><b>EV:</b> define the exposure compensation. Positive number provides brighter images, while negative number provides darker images. EV is not available in manual exposure mode.</p> <p><b>BLC:</b> select the area for backlight compensation. Only available when auto exposure mode is selected. Below is a reference of the area size of the available options:</p> <div style="text-align: center;">  </div> <p><b>Frequency:</b> select power line frequency. Only available on flickerless mode.</p> <p><b>Shutter speed:</b> define shutter speed. Only available on shutter priority or manual mode.</p> <p><b>Gain:</b> define intensity of lights coming into the camera. Only available on manual mode.</p>
---	---------------	--




2	Day night switch control	<p><b>Mode:</b> select day night mode. Auto mode is not available on manual exposure mode.</p> <ul style="list-style-type: none"> <li>- Auto: camera automatically switch modes depending on the lighting conditions</li> <li>- Color or B/W: camera keeps selected mode regardless of the lighting conditions.</li> </ul> <p><b>Time:</b> set buffer time for switching modes. Not available on manual exposure mode.</p> <p><b>Sensitivity:</b> define sensitivity for switching mode. Not available on manual mode.</p>
3	IR control	<p><b>IR mode:</b> select IR mode.</p> <ul style="list-style-type: none"> <li>- Auto: camera automatically switch modes depending on the lighting conditions</li> <li>- On or Off camera keeps selected mode regardless of the lighting conditions.</li> </ul>



	<p><b>Smart IR:</b> when enabled, the camera dynamically adjusts shutter speed and sensor gain to prevent overexposure. Note: digital WDR will be activated when Smart IR is enabled.</p> <p><b>Adjustable IR level:</b> manually adjust the IR level. Only available when adaptive IR is off.</p>
--	--


## 5.2.2 White Balance

This section allows user to set the white balance values to meet ambient conditions for best color rendition.



1	Basic setting	<p><b>Mode:</b> select white balance mode.</p> <ul style="list-style-type: none"> <li>- Auto: adjusts color balance in accordance with any change in color temperature.</li> <li>- ATW: automatically controls color temperature ranging from 2500°K to 10000°K.</li> <li>- Manual: manually adjust red and blue color on the image. Click one push for camera to adjust proper gain values depending on current environment conditions.</li> </ul>
---	---------------	---

## 5.2.3 Basic Setting



1	Quality	<p><b>Sharpness:</b> adjust image sharpness. Higher value provides sharper images.</p> <p><b>3D noise reduction:</b> analyzes sequence of frames to filter out pixels that likely represent noise. Higher value provides higher effect of noise reduction but may create motion blur.</p> <p><b>Gamma correction:</b> set gamma correction for accurate image display on different screen.</p>
2	Color	<p><b>Brightness:</b> adjust image brightness. Higher value provides brighter images.</p> <p><b>Contrast:</b> adjust image contrast. Higher value provides higher contrast images.</p> <p><b>Saturation:</b> adjust image saturation. Lower value provides images in grayscale.</p> <p><b>Hue:</b> adjust image hue. Higher value provides deeper hue effect.</p>
3	Image rotation	Select image orientation.



## 5.3 Video

### 5.3.1 Privacy Zone

Privacy zone enables user to black out a specific portion of the image. Privacy zone will apply to all streams, TV output, and Live View and it does not affect motion detection.

①

Basic Setting

- Zone-1
- Zone-2
- Zone-3
- Zone-4
- Zone-5
- Zone-6
- Zone-7
- Zone-8

Privacy Color Setting


Black

Enable

On  Off

Zone Setting

Clean



1	Basic setting	<p><b>Privacy color setting:</b> select color for the privacy zone from the dropdown menu.</p> <p><b>Enable:</b> select on/off to enable/disable the privacy zone.</p> <p><b>Zone setting:</b> click clean to delete the privacy zone.</p>
---	---------------	--

### 5.3.2 Enhanced Codec

Enhanced Codec features iZone and iStream technologies to exert leverage between different regions and compression level, effectively optimizing bandwidth usage.

①

Basic Setting

Off

iZone

Zone 1

Level: Mid

Save Clean

Zone 2

iStream

Level: High

Mode: EcoZone+EcoFrame

Dynamic 3DNR: Off



1	Basic setting	<p><b>iZone</b> allows users to designate an area for enhancing image quality. The undefined area will have higher compression ratio to match target bitrate. To draw an area, left click on the image and drag to outline the desired zone. Select the level for the zone and click save to apply the new changes or click clean to delete the settings.</p> <p><b>iStream</b> EcoZone mode automatically identifies dynamic motions and applies higher compression level to the static background. Rate control settings will not be available when using EcoZone. EcoZone+EcoFrame mode additionally reduces iframe on minor motions scene. When using EcoFrame, GOP settings will not be available.</p> <p>Dynamic 3DNR automatically adjusts noise reduction level according to the environment conditions. When dynamic 3DNR is enabled, 3DNR under images will not be available.</p>
---	---------------	---



## 5.4 Network

### 5.4.1 General

This section is for user to set detailed settings related to wired network condition for the camera.

①

Basic Setting	
Device Name	PM1
HTTP Port	80 (80, 1025-65535)
Enable LDAP	Off
Bonjour	Off
WS Discovery	On
View Current Network Settings	<a href="#">View</a>

1	Basic setting	<p><b>Device Name:</b> enter device name.</p> <p><b>HTTP Port:</b> insert desired HTTP port. Default port number is 80.</p> <p><b>Enable LDAP:</b> select on/off to enable/disable Lightweight Directory Access Protocol.</p> <p><b>Bonjour:</b> select on/off to enable/disable Bonjour protocol.</p> <p><b>WS Discovery:</b> select on/off to enable/disable web service discovery.</p> <p><b>View Current Network Settings:</b> click view to see current network related settings.</p>
---	---------------	--

②

IP Settings	
Mode	DHCP
APIPA	Off
IPv4 Address	192.168.1.219
IPv4 Subnet Mask	255.255.255.0
IPv4 Default Gateway	192.168.1.254
IPv6 Enable	<input type="checkbox"/>
Accept IPv6 router advertisements	Off
Enable DHCPv6	Off
IPv6 Address	
Subnet prefix length	(1~128)
IPv6 default router address	
Subnet prefix length	(1~128)
IPv6 DNS	

2	IP settings	<p><b>Mode:</b> select mode according to your needs. Available options: manual, PPPoE, DHCP.</p> <p><b>APIPA:</b> select on/off to enable/disable automatic private IP addressing.</p> <p><b>IPv4 address:</b> insert IP address.</p> <p><b>IPv4 subnet mask:</b> default is 255.255.255.0.</p> <p><b>IPv4 Default Gateway/Primary DNS/Secondary DNS:</b> default is blank. Not mandatory field.</p> <p><b>IPv6 enable:</b> check box to enable IPv6 protocol.</p> <p><b>Accept IPv6 router advertisements:</b> select on to enable router advertisement.</p> <p><b>Enable DHCPv6:</b> enable for camera to obtain IPv6 address from DHCP server.</p> <p><b>IPv6 address:</b> insert IP address</p> <p><b>Subnet prefix length:</b> set prefix length for subnet.</p> <p><b>IPv6 default router address:</b> set a default router address under IPv6 protocol.</p> <p><b>Subnet prefix length:</b> set prefix length for subnet.</p> <p><b>IPv6 DNS:</b> set a Domain Name Server under IPv6 protocol.</p>
3	Wired setting	<p><b>Speed &amp; Duplex:</b> half duplex can only send or receive info at a time. Full duplex can receive and send info simultaneously. Auto allows camera to decide which mode to adopt.</p>
4	UPnP	<p><b>Enable UPnP:</b> select on/off to enable/disable Universal Plug &amp; Play.</p> <p><b>Mode:</b> select identification mode. Available options: device name and MAC, device name, user input.</p>



5	SSL	<p><b>Enable SSL:</b> select on to enable HTTP and HTTPS. Select off to enable HTTP only. Select HTTPS only to enable HTTPS only. When HTTPS only is enabled, web port 80 will be disabled. Before enabling SSL, please install or generate SSL.</p> <p><b>HTTPS Port:</b> define HTTPS port. It is recommended to use default port number 443.</p>
---	-----	---

### 5.4.2 FTP Server

This section allows user to enable camera as FTP server. To log into the FTP server and access the SD card, open a browser and enter ftp://<Login ID>:<Password>@<ip address>. The default setting is ftp://admin:1234@192.168.0.30. The maximum connection for FTP server is 30.

①

**Basic Setting**

Enable

Port  (21, 1025-65535)

1	Basic setting	<p><b>Enable:</b> select on/off to enable/disable FTP server.</p> <p><b>Port:</b> input a value or use default port 21 to activate the FTP server function.</p>
---	---------------	---

### 5.4.3 SFTP Server

SFTP is a network protocol used for transferring files via a more secure channel than FTP. To log into the SFTP server and access the SD card, open a browser and enter sftp://<Login ID>:<Password>@<ip address>. The default setting is sftp://admin:1234@192.168.0.30. The maximum connection for SFTP server is 30.

①

**Basic Setting**

Enable

Port  (1025-65535)

1	Basic setting	<p><b>Enable:</b> select on/off to enable/disable SFTP server.</p> <p><b>Port:</b> input a value to activate the SFTP server function.</p>
---	---------------	--

### 5.4.4 RTSP

Configure RTSP to allow 3<sup>rd</sup> party devices to access the camera's stream. Note: when codec related information is changed, the RTSP server will be restarted.

①

**Basic Setting**

Authentication  Port  (554,1025-65535)

Multicast Auto Connection

②

**Stream1**

URL  Metadata

**Multicast Address Setting**

Address Type	<input type="text" value="Auto"/>	Multicast URL	<input type="text" value="stream1m"/>
Video Address	<input type="text" value="239.168.1.219"/>	Video Port	<input type="text" value="3310"/> (1025-65535, even number)
Audio Address	<input type="text" value="239.168.1.219"/>	Audio Port	<input type="text" value="2144"/> (1025-65535, even number)
Meta Address	<input type="text" value="239.168.1.219"/>	Meta Port	<input type="text" value="2882"/> (1025-65535, even number)

**Stream2**

URL  Metadata

**Multicast Address Setting**

Address Type	<input type="text" value="Manual"/>	Multicast URL	<input type="text" value="stream2m"/>
Video Address	<input type="text" value="231.0.0.222"/>	Video Port	<input type="text" value="1500"/> (1025-65535, even number)
Audio Address	<input type="text" value="231.0.0.222"/>	Audio Port	<input type="text" value="1600"/> (1025-65535, even number)
Meta Address	<input type="text" value="231.0.0.222"/>	Meta Port	<input type="text" value="1700"/> (1025-65535, even number)



1	Basic setting	<p><b>Authentication:</b> select on/off to enable/disable authentication on RTSP connection.</p> <p><b>Multicast auto connection:</b> select on/off to enable automatic multicast mode.</p> <p><b>Port:</b> insert port number or use default port number 554.</p>
2	Stream	<p><b>URL:</b> insert name for unicast URL. To access from other device, enter the following address: rtsp://(camera IP address)/(URL name). For example: rtsp://192.168.1.219/URL stream1</p> <p><b>Metadata:</b> select on/off to enable/disable metadata.</p> <p><b>Multicast URL:</b> insert name for multicast URL. To access from other device, enter the following address: rtsp://(camera IP address)/(Multicast URL stream 1). For example: rtsp://192.168.1.219/ Multicast URL stream 1</p> <p><b>Address type:</b> select auto to keep original camera settings or select manual to set different address and port for video and meta.</p> <p><b>Video and Meta Address/Port:</b> when selecting manual address type, users can define each address and port individually.</p>

### 5.4.5 SNMP

SNMP is a protocol used for monitoring and managing the status of devices connected to the networks.

The screenshot shows the SNMP configuration page with the following elements:

- 1:** SNMP v1 Enable dropdown menu.
- 2:** SNMP v2c Enable dropdown menu, Read Community String (public), Write Community String (private), and Trap Community String (public) fields.
- 3:** SNMP v3 Enable dropdown menu, Authentication Mode (NONE), Privacy Mode (NONE), User Name (initial), Authentication Password, and Privacy Password fields.
- 4:** Trap Mode (Off), Heartbeat (Off), Event (Off) dropdown menus, and Target IP and Heartbeat Interval (30) fields.
- 5:** Download MIB button.

1	SNMP v1	Enable: select on/off to enable/disable SNMP v1.
2	SNMP v2c	Enable: select on/off to enable/disable SNMP v2c.
3	SNMP v3	Enable: select on/off to enable/disable SNMP v3.
4	Trap	<p><b>Mode:</b> select SNMP mode to be enabled with trap or select off to disable trap.</p> <p><b>Target IP:</b> input the IP address of the SNMP server.</p> <p><b>Heartbeat:</b> is a communication protocol that sends notifications in a given interval to ensure network free from delayed notifications. Select on/off to enable/disable heartbeat function.</p> <p><b>Heartbeat interval:</b> define values in seconds for heartbeat interval.</p> <p><b>Event:</b> select on/off to enable/disable event logs.</p>
5	Download MIB	Click download to get specifics of MIB. MIBs describe the structure of the management data of a device subsystem; which uses a hierarchical namespace containing object identifiers (OID). Each OID identifies a variable that can be read or set via SNMP.





## 5.4.6 802.1X

802.1X defines the encapsulation of the EAP over LAN.

① **Basic Setting**  
Protocol

1	Basic setting	<b>Protocol:</b> select a desired EAP protocol from the dropdown menu and input required subfields to complete setup. Inner authentication mode can support CHAP, EAP-MSCHAPV2, MD5, MSCHAP, MSCHAPV2 and PAP.
---	---------------	--

## 5.4.7 Firewall

This section allows users to manually define multiple IP addresses to be allowed or denied access to camera.

① **Basic Setting**

Mode	<input type="text" value="Off"/>	
Filter	Enable	IP Address
1	<input type="checkbox"/>	<input type="text"/>
2	<input type="checkbox"/>	<input type="text"/>
3	<input type="checkbox"/>	<input type="text"/>
4	<input type="checkbox"/>	<input type="text"/>
5	<input type="checkbox"/>	<input type="text"/>
6	<input type="checkbox"/>	<input type="text"/>
7	<input type="checkbox"/>	<input type="text"/>
8	<input type="checkbox"/>	<input type="text"/>
9	<input type="checkbox"/>	<input type="text"/>
10	<input type="checkbox"/>	<input type="text"/>

1	Basic setting	<b>Mode:</b> select allow/deny to allow/deny access to IP address or select off disable this feature. <b>IP Address:</b> after selecting mode, insert IP addresses to activate the filters.
---	---------------	--

## 5.4.8 DDNS

DDNS can automatically upgrade DSN records without further manual editing in a real time manner, therefore resulting in web address directing faster and smoother.

① **Basic Setting**

Enable	<input type="text" value="Off"/>
Type	<input type="text" value="DynDNS"/>
Hostname	<input type="text"/>
User Name	<input type="text"/>
Password	<input type="text"/>

1	Basic setting	<b>Enable:</b> select on/off to enable/disable DDNS. <b>Type:</b> select type. DynDNS provides service with fee collection, while No-IP, Two-DNS and FreeDNS provide free services, but you must register first before enabling. <b>Hostname:</b> define hostname for DDNS. <b>User name / Password:</b> define credentials for accessing DDNS. <b>Hash:</b> mandatory field when selecting FreeDNS.
---	---------------	--



## 5.4.9 SSL

SSL allows sensitive information such as login credentials to be transmitted securely. SSL method available options include none, self-signed, request and upload certificate.

- None: no SSL method enabled.
- Self-signed: private own key that has no connection with person or organization that performs authorized certificate signing procedure. User can create CSR by filling required fields.
- Request: provides users with a download option of the created certificate for future use.
- Upload certificate: this option allows users to upload a previously created certificate.

## 5.4.10 QoS

QoS allows resource control and traffic prioritization mechanisms to ensure performance on data flow.

1	Basic setting	<b>Enable:</b> select on/off to enable/disable QoS.
2	QoS priority	<b>IPv4 address:</b> input IPv4 address. <b>Netmask bit:</b> Define value in response to the IPv4 address assigned.

## 5.5 System

### 5.5.1 Date & Time

1	Basic setting	<b>Current server time:</b> displays the current date/time. <b>Synchronization mode:</b> select the synchronization mode for camera date and time. <ul style="list-style-type: none"> <li>- Manually setting date and time: allows users to manually set date and time.</li> <li>- Synchronize with PC: automatic sync to connected pc date and time.</li> <li>- Synchronize with NTP server: automatic sync to assigned NTP server.</li> </ul>
---	---------------	--



2	NTP setting	<p><b>Enable:</b> select enabled mode for NTP server.</p> <ul style="list-style-type: none"> <li>- Manual: allows user to input desired NTP server address.</li> <li>- From DHCP server: obtains NTP server address assigned by DHCP server.</li> </ul> <p><b>Server address:</b> input NTP server address.</p> <p><b>Synchronization period:</b> define synchronization period in terms of hour.</p>
3	Time zone setting	<p><b>Time zone:</b> select a region then select the corresponding city.</p>

### 5.5.2 Firmware

This section allows users to view system information and upgrade firmware. Camera will stop all functions during firmware upgrade and reboot itself after process is finished. When upgrading firmware, do not disconnect power or LAN cable or it will result in upgrade failure, requiring manufacturer maintenance.

**System Information**

Firmware Version	01.05.0.9.21360
Hardware Version	00.00
Product Name	SR-C-A2-DF1-F3-IR
Serial Number	AS213100085
MAC Address	20:e4:07:00:47:98

**Firmware Upload**

### 5.5.3 Initialization

1

Camera Type

2

TV Format

3

Import Setting

4

Export Setting

5

Configuration Setting

1	Camera type	Select proper power frequency to avoid flickering by fluorescent light.
2	TV format	Allows users to select the appropriate aspect ratio to fit monitor.
3	Import setting	Allows users to import previously exported camera configuration.
4	Export setting	Allows users to download camera configuration for future use.
5	Configuration setting	<p><b>Reboot:</b> click to reboot camera</p> <p><b>Software factory default:</b> reset all to factory default except network settings.</p> <p><b>Hardware factory default:</b> reset all configuration to factory default.</p>



## 5.5.4 OSD

1

**Basic Setting**

**OSD 1**

Enable:

Background Color:

Text Color:

Location X:  (1~10)

Location Y:  (1~10)

**OSD 2**

Enable:

Background Color:

Text Color:

Location X:  (1~10)

Location Y:  (1~10)

2

**Event**

Background Color:

Text Color:

Location X:  (1~10)

Location Y:  (1~10)

1	Basic setting	<p>Users can setup up to 2 OSD settings concurrently.</p> <ul style="list-style-type: none"> <li>- Enable: select on/off to enable/disable OSD.</li> <li>- Background color: select OSD background color.</li> <li>- Text color: select OSD text color.</li> <li>- Location X/Y: define location within the x and y axis.</li> </ul>
2	Event	<p>Users can configure OSD triggered by event.</p> <ul style="list-style-type: none"> <li>- Background color: select OSD background color.</li> <li>- Text color: select OSD text color.</li> <li>- Location X/Y: define location within the x and y axis.</li> </ul>

## 5.5.5 Events

1

**Basic Setting**

No.	Event Type	Start Time	End Time
1	motion	2017/06/07 03:41:58	2017/06/07 03:42:03
2	motion	2017/06/07 03:42:03	2017/06/07 03:42:04
3	tamper	2017/06/07 03:41:59	2017/06/07 03:42:01
4	tamper	2017/06/07 03:42:01	2017/06/07 03:42:03
5	tamper	2017/06/07 03:42:03	2017/06/07 03:42:05
6	schedule	2017/06/07 03:42:21	2017/06/07 03:42:26
7	schedule	2017/06/07 03:42:27	2017/06/07 03:42:32

2

**Filter**

**Event Type**

Tamper       Motion

Network Loss       Schedule

Alarm       Audio

**Time**

All the time

Manual

Start Time:

End Time:

**Analysis**

■ motion:2  
■ tamper:3  
■ audio:0  
■ schedule:2  
■ alarm:0  
■ network:0

3

1	Event list	Displays all events from search criteria. Click refresh to update list. Click clean up to clear.
2	Filter	<p>Select filters then click search to look for specific events.</p> <p><b>Event type:</b> select the event type you would like to search.</p> <p><b>Time:</b> select manual to manually input time frame or select all the time to search all.</p>
3	Analysis	Overview of how frequent each event has been triggered.



## 5.5.6 Web Log

1

Sender Settings

Enable	<input type="text" value="On"/>
Server Address	<input type="text"/>
Port	<input type="text" value="25"/>
Authentication	<input type="text" value="No_Auth"/>
User Name	<input type="text"/>
Password	<input type="password"/>
Sender Email Address	<input type="text"/>
Status	fail

1	Sender settings	<p><b>Enable:</b> select on/off to enable/disable this function.</p> <p><b>Server address:</b> input a designated server address that can access camera web log.</p> <p><b>Port:</b> define port number or set default 25.</p> <p><b>Authentication:</b> select an authentication type.</p> <p><b>User name / Password:</b> input credentials.</p> <p><b>Sender email address:</b> define the sender email address.</p> <p><b>Status:</b> displays connection status between camera and server.</p> <p><b>Save and test:</b> click to check if server connection has been successfully established.</p> <p><b>Download:</b> click to create a system log that can be used for troubleshooting.</p>
---	-----------------	--

## 5.6 Account

### 5.6.1 Account Management

This section allows admin to manage up to 10 user accounts. Each user will be assigned an access level.

- Admin: have access to all camera configurations. Default user name admin cannot be deleted.
- Operator: can only access camera live view, storage, and remote lens control functions.
- User: can only access camera live view functions.

Note: username cannot be repeated. Password must be 4-16 characters long with valid alphanumeric value.

Account Setting

User List

No.	Access Level	User name
0	Admin	admin
-	-	-

Setup Session Lifetime

Session Lifetime



## 5.6.2 LDAP

①

②

③

**Basic Setting**

Server

Port  (389, 1025~65535)

Base DN

Bind DN Template

Search Template

---

**Group Mappings**

Admins

Operators

Users

---

**Authentication**

User Name

Password

Enable TLS

1	Basic setting	<p><b>Server:</b> input server.</p> <p><b>Port:</b> input port number. Default port number is 389.</p> <p><b>Base DN/ Bind DN Template/ Search Template:</b> these strings are updated by the LDAP server to be accessed. Refer to these fields for future configurations.</p>
2	Group mappings	<p><b>Admins / Operators / Users:</b> these strings are updated by the LDAP server to be accessed. Refer to these fields for future configurations.</p>
3	Authentication	<p><b>User name / Password:</b> Enter designated credentials for authentication.</p> <p><b>Enable TLS:</b> select on/off to enable/disable LDAP over TLS after uploading certificate. To enable TLS, users must upload a CA file first. To delete CA file, click delete.</p> <p>Note: (1) Before enabling TLS, please install or generate SSL certificate first. (2)-Before actually start using LDAP, user must enable LDAP.</p>

## 5.7 Event Source

The table below gives an overview of event source configurations and dependencies.

Type	Event specific	Handler	Arming schedule	Not supported features
<b>Defog</b>	On/Off	V	V	
<b>Motion</b>	Set zone 1~4, object size and sensitivity	V	V	
<b>Network</b>	Wired Network Loss/ Wired Network Conflict	V	-	Snapshot, e-mail alarm, HTTP Generic Event
<b>Schedule</b>	Regular/Persist trigger event action (without event source as premise)	V	V	OSD alarm, HTTP Generic Event
<b>Tamper</b>	Sensitivity	V	V	
<b>mSD Healthiness</b>	Free space/Mount Failure	V	-	Snapshot, recording



### 5.7.1 Handlers

**Snapshot:** when enabled, users can choose to store event snapshot to edge (SD card) or remote FTP server. Note that under Handler, the camera act as FTP client and remote device as FTP server. FTP server path must be configured in advance.

**Recording:** when enabled, camera can save recorded video to the SD card when event occurs.

**Email:** when enabled, an email will be sent to a predefined user when event occurs. Users can configure email subject and message content.

**OSD:** when enabled, OSD will display on screen when event occurs. Users can configure OSD text.

**HTTP generic event:** when enabled, HTTP generic event function will activate when event occurs. There are 10 method types available to choose for message notification.

### 5.7.2 Arming Schedule Setting

This section allows user to set up a schedule for recording video when alarm input signal occurs.

**Arming Schedule Setting**

<a href="#">Edit</a>	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Monday																									
Tuesday																									
Wednesday																									
Thursday																									
Friday																									
Saturday																									
Sunday																									

The table displays the 7days of the week in a 24hrs format, highlighting the alarm recording schedule. To configure the schedule, click on edit. Users can configure up to 3 individual time range per day by defining start and end time. Click apply for the new configuration to take effect.

### 5.7.3 Defocus

This page is designed to establish related actions when the camera is defocus.

**Basic Setting**

Enable

---

**Handlers**

<p><b>Snapshot</b></p> <p><input type="checkbox"/> Store to Edge</p> <p><input type="checkbox"/> Store to FTP</p>	<p><b>Recording</b></p> <p><input type="checkbox"/> Edge Record</p>	
<p><b>Email</b></p> <p>Enable <input type="checkbox"/></p> <p>Subject <input type="text"/></p> <p>Message <input type="text"/></p>	<p><b>OSD</b></p> <p>Enable <input type="checkbox"/></p> <p>Text <input type="text"/></p>	<p><b>HTTP Generic Event</b></p> <p>Enable <input type="checkbox"/></p> <p>Method <input type="text" value="1"/></p>

1	Basic setting	<b>Enable:</b> check the box to enable defocus function.
---	---------------	--

### 5.7.4 Motion

This page is designed to establish related actions when the camera detects motion. Users can configure up to 4 motion detection areas.



1

1	Basic setting	<p><b>Enable:</b> draw the motion detection area on the image then enable and click save.</p> <p><b>Object Size:</b> define object size for triggering motion detection.</p> <p><b>Sensitivity:</b> define motion detection sensitivity.</p> <p><b>Zone:</b> check the box to enable each zone setting.</p>
---	---------------	---

### 5.7.5 Network

This page is designed to configure related actions when the camera is subject to network related issues.

1

1	Basic setting	<p><b>Wired network loss:</b> check the box to enable the detection of network lost.</p> <p><b>Wired network conflict:</b> check the box to enable the detection of IP address conflict.</p>
---	---------------	--

### 5.7.6 Schedule

This page is designed to configure related actions for recording schedule, independently of any event.

1

1	Basic setting	<p><b>Enable:</b> check the box to enable recording schedule function.</p>
---	---------------	--





	<p><b>Mode:</b> Under regular mode, the camera will record only when event is triggered within the scheduled time frame, while persistent mode will always record within the schedule time.</p> <p><b>Trigger interval:</b> define the event trigger interval in terms of seconds.</p>
--	--

### 5.7.7 Tamper

This page is designed to configure related actions when the camera is subject to tamper events.

1

Basic Setting

Enable  Sensitivity Mid

**Handlers**

Snapshot	Recording
<input type="checkbox"/> Store to Edge	<input type="checkbox"/> Edge Record
<input type="checkbox"/> Store to FTP	

Email	OSD	HTTP Generic Event
Enable <input type="checkbox"/>	Enable <input type="checkbox"/>	Enable <input type="checkbox"/>
Subject <input style="width: 80%;" type="text"/>	Text <input style="width: 80%;" type="text"/>	Method <span style="border: 1px solid #ccc; padding: 2px;">1</span>
Message <input style="width: 95%; height: 20px;" type="text"/>		

1	Basic setting	<p><b>Enable:</b> check the box to enable tamper detection.</p> <p><b>Sensitivity:</b> define tamper sensitivity.</p>
---	---------------	---

### 5.7.8 MSD Healthiness

This page is designed to configure related actions regarding MicroSD issues.

1

Basic Setting

**Free space** ⊘

Enable Warning Size 


 50 (50-1000MB)

**Handlers**

Email	OSD	HTTP Generic Event
Enable <input type="checkbox"/>	Enable <input type="checkbox"/>	Enable <input type="checkbox"/>
Subject <input style="width: 80%;" type="text"/>	Text <input style="width: 80%;" type="text"/>	Method <span style="border: 1px solid #ccc; padding: 2px;">1</span>
Message <input style="width: 95%; height: 20px;" type="text"/>		

**Mount failure** ⊘

1	Basic setting	<p><b>Free space:</b> check the box to enable the detection of insufficient space of the inserted microSD card. Define the threshold for trigger by sliding the warning size bar.</p> <p><b>Mount failure:</b> check the box to enable the detection of failure of the inserted microSD card.</p>
---	---------------	---

## 5.8 Event Setting

### 5.8.1 Email

This page allows users to set up email notification when event occurs. Make sure you have enabled email sending in each event section to activate this function.



①

②

③

**Basic Setting**

Authentication: No\_Auth (dropdown)

Server Address: [text input]

Port: [text input]

User Name: [text input]

Password: [text input]

**Sender Settings**

Sender Email Address: [text input]

Attach Image: Off (dropdown)

**Email Address List**

No.	Enable	Email Address
1	<input type="checkbox"/>	[text input]
2	<input type="checkbox"/>	[text input]
3	<input type="checkbox"/>	[text input]
4	<input type="checkbox"/>	[text input]
5	<input type="checkbox"/>	[text input]
6	<input type="checkbox"/>	[text input]
7	<input type="checkbox"/>	[text input]
8	<input type="checkbox"/>	[text input]
9	<input type="checkbox"/>	[text input]
10	<input type="checkbox"/>	[text input]

1	Basic setting	<p><b>Authentication:</b> select an authentication type.</p> <p><b>Server address:</b> input a designated server address for email notification.</p> <p><b>Port:</b> set default port number 25 or change to dedicated number.</p> <p><b>User Name / Password:</b> input credentials with privilege to access the server.</p>
2	Sender setting	<p><b>Sender email address:</b> define the sender email address.</p> <p><b>Attach image:</b> select on/off to enable/disable attaching the event image on the email.</p>
3	Email address list	<p><b>Enable:</b> check the box to send email to the selected address.</p> <p><b>Email address:</b> input an email address to which events notifications will be sent.</p>

### 5.8.2 FTP

This page allows users to set up FTP image storing when event occurs. Make sure you have enabled FTP function in each event section to activate this function.

①

**Basic Setting**

Server Address: [text input]

Port: [text input] (21, 1025-65535)

User Name: [text input]

Password: [text input]

Mode: Active (dropdown)

1	Basic setting	<p><b>Server address:</b> input FTP server address.</p> <p><b>Port:</b> set default port 21 or change to dedicated number.</p> <p><b>Username / Password:</b> input credentials with privilege to access the server.</p> <p><b>Mode:</b> select connection mode to be use.</p> <ul style="list-style-type: none"> <li>- Active: the camera maintains connection with the designated FTP site, which provides instant response to FTP.</li> <li>- Passive: the camera connects with the designated FTP site only when necessary, which reduces network bandwidth.</li> </ul>
---	---------------	---

### 5.8.3 Record Setting

This page allows users to configure recording. Make sure you have enabled recording in each event section to activate this function.



1

Basic Setting

Record Type	Video
Record Status	One Shot
Clip Duration	5 (5~10 Sec)
Clip Size	50 (50~100 MB)
Record Codec	H264

1	Basic setting	<p><b>Record type:</b> choose recording type.</p> <p><b>Record status:</b> define the method of recording. Select one shot for camera to record video with designated duration and file size or select continuous for camera to record continuously.</p> <p><b>Clip duration:</b> set the length limit for recording file.</p> <p><b>Clip size:</b> define the file size for recording file.</p> <p><b>Record codec:</b> choose type of video codec.</p>
---	---------------	--

### 5.8.4 SD card

This page allows users to configure edge recording when event occurs. Make sure you have enabled edge recording in each event section to activate this function.


1

Basic Setting

Overwrite	Off	(Reserve 20MB)
Status	Working normally	
Capacity	3713(MB)	
Free Space	3698(MB)	
Encrypted Mode	On	Note: SD card will be formatted if switch this mode!
Encryption Key	[Redacted]	
SD Format	Format	

1	Basic setting	<p><b>Overwrite:</b> select on/off to enable/disable overwrite. When enabled and SD card capacity is below 20MB, old files will be overwritten to store new ones.</p> <p><b>Status:</b> shows the status of SD Card. Possible status includes: (1) SD card not inserted, (2) working normally, (3) unsupported filesystem, please format the SD card to ext4.</p> <p><b>Capacity:</b> shows the capacity of the inserted SD card.</p> <p><b>Free space:</b> shows the available space of the inserted SD card.</p> <p><b>Encrypted mode:</b> select on/ off to enable/disable encryption for the data on the SD card.</p> <p><b>Encryption key:</b> available when encryption mode is enabled. Encryption key allows user to enter a password, which will be used for decrypting and access the video file.</p> <p><b>SD format:</b> click to start formatting the mounted SD card. All data in the SD card will be deleted, regardless of encryption mode.</p>
---	---------------	---

Recorded files on SD card can be download. To download, select date on calendar and click search. Available videos will be displayed on the right. Select the videos you want to download then click download.



### 5.8.5 Snapshot

This page allows users configure snapshots when event occurs. Make sure you have enabled snapshot in each event section to activate this function.

1

**Basic Setting**

Pre Event Capture Count  (1~10 Frame)

Event Capture Interval  (1~10 Sec)

Post Event Capture Count  (1~infinite Frame)

1	Basic setting	<p><b>Pre event capture count:</b> set a number of frames to be captured prior to an event.</p> <p><b>Event capture interval:</b> set a time interval ranging between each snapshot capture.</p> <p><b>Post event capture count:</b> set a number of frames to be captured after an event occurs.</p>
---	---------------	---

### 5.8.6 HTTP Generic Event

This page allows users to configure messages and commands directly to Network Video Recorder (NVR) which supports CGI command function.

1

**Basic Setting**

Method	Title	<input type="text"/>
1	URL	<input type="text"/>
2	Option	Get <input type="text"/>
3	User Name	<input type="text"/>
4	Password	<input type="text"/>
5	Active Message	<input type="text"/>
6	Inactive Message	<input type="text"/>
7		

1	Basic setting	<p><b>Method:</b> select the type of method for the trigger event.</p> <p><b>Title:</b> insert the title for the messages.</p> <p><b>URL:</b> Input the NVR's URL. Please follow NVR's user manual.</p> <p><b>Option:</b> select the mode of notification transmission as needed.</p> <ul style="list-style-type: none"> <li>- Get: simple and fast method to transmit messages but less secure than post.</li> <li>- Post: more complex way to transmit messages, but safer than get.</li> </ul> <p><b>User Name / Password:</b> enter designated credentials for authentication to the NVR.</p> <p><b>Active message:</b> camera will send an active message to NVR when the event occurs.</p> <p><b>Inactive Message:</b> camera will send an inactive message to NVR when the event ends.</p>
---	---------------	---



**HQ**

Via Antonio Gramsci, No. 86/A  
42124 Reggio Emilia, Italy  
Tel. +39 0522 929850  
info@spark-security.com

**Asia office**

No. 45, Aikou 2nd Rd., Zhubei City,  
302053 Hsinchu County, Taiwan  
Tel. +886 3 575 2786  
info@spark-security.com.tw

For more information, please visit us at [www.omnieye-security.com](http://www.omnieye-security.com)